


## REPLACEABLE RUBBER TIP (ROUND)



PARTS NO	DIMENSIONS		RUBBER TIP HOLDER
	INCH	MM	
RR-010	0.010	0.25	1.6 RSB Holder
RR-012	0.012	0.30	1.6 RSB Holder
RR-016	0.016	0.40	1.6 RSB Holder
RR-020	0.020	0.50	1.6 RSB Holder
RR-025	0.025	0.63	1.6 RSB Holder
RR-030	0.030	0.76	1.6 RSB Holder
RR-035	0.035	0.89	1.6 RSB Holder
RR-040	0.040	1.02	1.6 RSB Holder
RR-045	0.045	1.14	1.6 RSB Holder
RR-050	0.050	1.27	1.6 RSB Holder
RR-060	0.060	1.52	1.6 RSB Holder
RR-070	0.070	1.78	1.6 RSB Holder
RR-080	0.080	2.03	1.6 RSB Holder
RR-090	0.090	2.29	1.6 RSB Holder
RR-100	0.100	2.54	1.6 RSB Holder
RR-110	0.110	2.79	1.6 RSB Holder
RR-120	0.120	3.05	1.6 RSB Holder
RR-130	0.130	3.30	1.6 RSB Holder
RR-140	0.140	3.56	1.6 RSB Holder
RR-150	0.150	3.81	1.6 RSB Holder
RR-160	0.160	4.06	1.6 RSB Holder
RR-170	0.170	4.57	1.6 RSB Holder
RR-200	0.200	5.08	1.6 RSB Holder
RR-220	0.220	5.59	2.6 RSC Holder
RR-240	0.240	6.10	2.6 RSC Holder
RR-260	0.260	6.60	2.6 RSC Holder
RR-280	0.280	7.11	2.6 RSC Holder
RR-300	0.300	7.62	2.6 RSC Holder
RR-320	0.320	8.13	2.6 RSC Holder
RR-340	0.340	8.64	2.6 RSC Holder
RR-360	0.360	9.14	2.6 RSC Holder
RR-380	0.380	9.65	2.6 RSC Holder
RR-400	0.400	10.16	2.6 RSC Holder
RR-420	0.420	10.67	2.6 RSC Holder
RR-440	0.440	11.18	2.6 RSC Holder
RR-460	0.460	11.68	2.6 RSC Holder
RR-480	0.480	12.00	2.6 RSC Holder
RR-500	0.500	12.70	2.6 RSC Holder
RR-550	0.550	13.97	2.6 RSC Holder
RR-600	0.600	15.24	2.6 RSC Holder